

## MODEL #115 LARGE LATTICE LED COUNTDOWN, STOPWATCH, ALARM CLOCK

### 2018 USER'S MANUAL

---

#### 1. "SET" KEY

Press the key at the first time for setting alarm clock.

Press the key at the second time for setting time, calendar

Press the key at the third time; it is in normal showing state of time.

#### 2. "MODE" KEY

- In normal showing state of time, it will show countdown display after you press that key at the first time, and press **"SNOOZE"** to start the countdown after the time is setup, and press it again for pausing, then press **"SNOOZE"** to start Countdown.
- It will get back to the normal state if you press the **"SNOOZE"** key after the countdown time is finished.(the maximum countdown time could be 23:59:59)
- It is a mobile mode switch in the alarm, time setting mode.
- In normal state, press the buttons **"MODE"** and **"UP"** at the same time, the date display mode could be changed to 3 different ways such as: "YY/MM/DD"(the buzzer will beep one time) or "DD/MM/YY"(buzzer will beep twice) or "MM/DD/YY"(beep three times) and the default way is "YY/MM/DD".

#### 3. "UP" KEY

- It is addend key when set snooze alarm, time, date and countdown time.
- It is toggle key of Celsius and Fahrenheit while it is showing temperature normally.

#### **4. "DOWN" KEY**

- It is subtraction key when set snooze alarm, time, calendar and countdown time.
- It is shift key between 24 hours or 12 hours in normal state.

#### **5. "SNOOZE" KEY**

1. In normal showing state of time, it will show temperature for few seconds after you press that key at the first time; and It will change into snooze function if you press the key while it is alarming.
2. It will be in mode of showing as "YY/MM/DD" or "DD/MM/YY" or "MM/DD/YY" when you press the key at the second time within 3 seconds.
3. Press the key at the third time within 3 seconds, it display 1st alarm.
4. Press the key at the fourth time within 3 seconds for checking 2nd alarm.
5. Press the key at the fifth time within 3 seconds for checking 3rd alarm.
6. Press the key at the sixth time within 3 seconds for checking 4th alarm.
7. Press the key at the seventh time within 3 seconds for checking 5th alarm.
8. Press the key at the eighth time within 3 seconds for checking 6th alarm.
9. Press the key at the 10th time for checking the time interval between each alarm ring within the 1st alarm. This time interval can be set as required.(1 to 60 minutes); The alarm sound is from slow to faster, from low to louder.
10. Press the key at the eleventh time or no any press of this key within 3 seconds, it will turn back to normal display of time mode, or calendar mode or temperature mode or circular display of this three modes.
11. All above can done with keeping pressing the key down, so that it could show all in turn.

#### **6. "AL ON/OFF" KEY**

1. Set on alarm after you press that key at the first time with buzzer
2. Press the second time for setting off

## 7. COMBINATION BUTONS — “UP & DOWN” KEY

- It turns to the temperature display interface from the normal time display interface, if you press **UP+DOWN** buttons at the same time at the first time
- Press them at the second time within 3 seconds, normally it shows the date in "YY/MM/DD".
- After the third time's press, it shows the time, temperature and date circularly.
- After the fourth's press within 3 seconds, it will shows the default time.

## 8. COMBINATION BUTONS — “MODE & DOWN” KEY

When you press “**MODE and DOWN**” at the same time it will enter a stopwatch (count up) mode, it will show 00:00:00, and press “**SNOOZE**” start to count up, press again the count up will be stopped with flashing, the minute and second flashing in circulation just 30seconds. It will show the default time.(the maximum countdown time could be 23:59:59) after you press **SNOOZE**. If you not press “**SNOOZE**” to stop, it will be 23:59:59 and then display the default time.