

MODEL #137 3" NUMERALS MULTI-ALARM CALENDAR WALL CLOCK

2018 USER'S MANUAL

A= EXIT B= DOWN/ALARM C= UP/12/24H D= SET

1. SETTING TIME AND CALENDAR

PRESS **SET**, the position of YEAR flashes, PRESS **DOWN OR UP** to adjust YEAR; then PRESS **SET**, the position of MONTH flashes, PRESS **DOWN OR UP** to adjust MONTH; then PRESS **SET**, the position of DATE flashes, PRESS **DOWN OR UP** to adjust DATE; then PRESS **SET**, the position of HOUR flashes, PRESS **DOWN OR UP** to adjust HOUR; then PRESS **SET**, the position of MINUTES flashes, PRESS **DOWN OR UP** to adjust MINUTES; PRESS **EXIT** TO EXIT after setting.

SETTING THE 12 HOUR/24 HOUR SYSTEM(only use back button)

PRESS C for 3 seconds to switch the 12 hours / 24 hours time system. When the 24 hour system is set the AM/PM buttons will not light. PRESS D TO EXIT to restore regular time showing.

2. ALARMS

SETTING THE ALARMS

When any alarm is set, the top button on left lights up.

- You can press DOWN consecutively to cycle through each alarm A1-A8 to see the alarm time which is set and to hear the alarm sound -

When any alarm is set, the top button on left lights up.

- You can press **DOWN** consecutively to cycle through each alarm A1-A8 to see the alarm time which is set and to hear the alarm sound -
- In the normal clock, press the B **DOWN** key to check the alarm status, the alarm lamp (top left) will light and at the temperature square it will show A1. You will see the first alarm information, and in hours and minutes it will show ——:—, the alarm is inactive until you change the digits as follows. Press the **UP** key, HH:MM will display “XX;XX”, then press the **SET** key to set the alarm clock time, the hour will start blinking, press **DOWN** or **UP** key to adjust digits, and then press the **SET** key to move to minute place, the minute will start blinking, press **DOWN** or **UP** key to adjust digits, then press **SET** to save.
- Press the **DOWN** key again for the next alarm setting and at the temperature square it will show A2, and then follow above instructions as in A1 to set the alarm
- In the same way, you can set any or all of the 8 alarms. When set-up is complete, press the A key to exit, and the clock time will display.

CANCEL THE ALARMS

In normal display, PRESS **DOWN** consecutively until you come to a set alarm showing the alarm time, and then PRESS **UP**, the time display should now show ——:— and this shows that this alarm is OFF. Repeat this step to cancel all 8 alarms, The alarm light (top left) will be off when all 8 alarms are cancelled. PRESS **EXIT TO EXIT**, after cancelling any alarms, to restore regular time showing. WHEN THE ALL ALARM CANCEL, THE ALARM LIGHT OFF.

SETTING HOURLY ALARM

(The bottom button on left lights when this alarm is on)

In normal display mode, PRESS **UP** to turn on/off hourly alarm. When the function is on, the clock will sound the alarm every hour at .00mins. Such as 1:00,2:00,3:00,4:00...11:00,12:00. The hourly alarm button, the top button on the right, lights when this function is on. PRESS **EXIT TO EXIT** to restore regular time showing.