

## MODEL #280 12" NUMERALS WATERPROOF GPS WALL CLOCK

### 2018 USER'S MANUAL

---

#### 1. OVERVIEW

- Connect the power cable on bottom of the clock and screw in tightly. Press the power on/off switch. Remote control uses A23 12 volt battery
- Press A once and 00:00 is flashing, then press B to choose either 12/24hour, press C to save
- Press A twice, to change the Hour, use B and C as UP and DOWN key
- Press A three times to change Minute, also use B and C to increase or decrease . Press C to save.
- The clock has internal GPS. Set the clock initially to the correct time. Then select time zone and after a short period the clock will adjust to accurate time. When placed outdoors the clock should have no problem receiving the satellite GPS signal. However if using indoors place near a window and experiment in different places if you do not receive the GPS signal to automatically adjust to the correct time.

#### 2. SETTING GPS

Press A four times, and it shows "on:20",

Press B to turn GPS ON .You can choose "On" or "Off"

When "On:20 is flashing, use Button B to choose different time zone and press C to save as follows:

US East	On:20
US Central	On:19
US Mountain	On:18
US West	On:17

US Alaska            On:16

US Hawaii            On:14

You can chose other time zones. Scroll through using B. After selection press C to save

On the bottom of the clock adjacent to the power on/off switch there are three buttons corresponding to A B and C. Use these buttons in an emergency if you have lost the remote and need to change a setting