

# BIGTIMECLOCKS®

 1-702 726-9030  
 [info@bigtimeclocks.biz](mailto:info@bigtimeclocks.biz)  
 [www.bigtimeclocks.biz](http://www.bigtimeclocks.biz)

**MODEL #114**  
**10" LED PLASMA**  
**WALL CLOCK**

## 2018 USER'S MANUAL

---

### 1. FUNCTIONS

1. Hour, minute display
2. 12 hours mode
3. Data saving

When the power is off, the LED display shuts down, but the IC can operate automatically, it is unnecessary to reset when the power is on.

### 2. INSTRUCTIONS

#### Button name (remote control ABC)

A. Setting button、 B. Increasing button、 C. Exiting button

#### Time setting

- When the time display is normal, press button“A” first time to set the time and you will see “Hour”flashing, press button“B” to adjust the “hour ”
- Press button “A”again to set “minute”, you will see “minute”flashing, press button “B”to adjust the “minute”
- In the process of setting, you can press “C” to quit the time setting function.