

# BIGTIMECLOCKS®

 1-702 726-9030  
 info@bigtimeclocks.biz  
 www.bigtimeclocks.biz

**MODEL #118**  
**5" LASER BLUE**  
**LED WALL CLOCK**

## 2018 USER'S MANUAL

---

### 1. FUNCTIONS

1. Hour, minute display
2. Data saving

When the power is off, the LED display shuts down, but the IC can operate automatically, it is unnecessary to reset when the power is on.

### 2. INSTRUCTIONS

#### Button name (remote control ABC)

A. Setting button/moving button、 B. Increasing button、 C. Exiting button

#### Time setting

- When the time display is normal, press button“A” first time to set the time and you will see “Hour”flashing, press button“B” to adjust the “hour ”
- Press button “A”again to set “minute”, you will see “minute”flashing, press button “B”to adjust the “minute”
- Press button “C” to save the setting automatically and return to the normal display.

**Remark:** Pressing button “C”during setting will save the current setting and will automatically exit but the setting will remain valid.